


T.M.G. Copier Rental

How To Install Sharp Printer On Mac


Download Driver

1. Go To [CopierRental.com](https://www.copierrental.com)

2. Open **Drivers** Tab



3. Select Printer Version From List (Version Can Be Found On The Front Of Printer)



4. Select **Operating System** (It May Automatically Find It)


- If Not Select OS Manually (To Find Your OS Version Go To **Apple Logo** At The Top Left Of Screen And select **About this Mac**)



T.M.G. Copier Rental

How To Install Sharp Printer On Mac

5. Select First Option Under **Printer Driver (Mac PS Driver)**



6. Click **Download** Button (At The Bottom Of The Page)


Install Driver

7. Open Downloaded Driver (May Be In Your Download Folder)

8. Run Driver (Box Icon)



9. Click **Continue** Through Program (It Will Ask You To **Agree**) Click **Install** And Enter Password (If Installed It Will Tell You **The installation was successful**)




T.M.G. Copier Rental

How To Install Sharp Printer On Mac

Install Printer

10. Open **System Settings** - Older Macs **System Preferences** (Gear Icon)
11. Open **Printers & Scanners**
12. Select **Add Printer Scanner or Fax** (Or + depending on Mac Version)



13. Choose Printer (Under Use It Should Say Sharp MX- [Printer Version], If Not Select It From Drop Down)

